



PROHIBITIONS

Smoking except in areas designed for this purpose



Eating or drinking in the industrial halls



Photographing or videotaping



Consuming alcohol or drogs, or being in possession of these products

- No parking of containers on the ground outside of the slab container
- · No parking on the rescue access, routes doors and shutters

GENERAL RISKS



Explosion







Explosive atmosphere

Speed limit in

the buildings

UNCOVERING / TARP TRUCKS



- Trucks must always be sheeted on the outside of buildings
- Use the uncovering/covering tarpaulin areas

TRAFFIC

Flammable





Place the wheel chocks on the parking

- · Respect the signs and the highway code
- Take the ways of pedestrian circulation
- Passengers are asked to wait at the reception

OBLIGATION TO COMMUNICATE



EMERGENCY NUMBER: 04 273 99 91 (Control room) 04 273 99 97 (Guard)

Any incident or irregularity (hazard, fuel leak, ...) and any near miss, accident or fire detected should be immediately reported to the Recyfuel manager

ALERT / Problem on the site

Interrupted audible signal

- Immediate stop to all operations of unloading/loading, evacuation of the hall. parking the truck in the parking lot. and stopping all engines
- Release of acces (roads, shutters and doors)
- Telephon communication forbidden
- · Evacuation of buildings and follow the instructions of **Recyfuel staff**

ALARM / Evacuation of the site

Continuous audible signal

· Same instructions in case of ALERT

(see indication on the map)

0

RESCUE EQUIPMENT

· Go immediately by food to the assembly point



ANY NON-COMPLIANCE WITH SAFETY/ENVIRONMENT INSTRUCTIONS CAN BE SANCTIONED BY THE IMMEDIATE AND PERMANENT BAN ON ACCESS TO THE SITE

